

P R I M A R E

THE SOUND AND VISION OF SCANDINAVIA

PRISMA Remote Design Brief

PRISMA Remote is essentially a Primare universal remote control, being capable of controlling virtually every function of every Primare model featuring IR remote control, as well as providing video display control:

- Easy to configure for use with both past and current Primare models using the information and following the steps found in the PRISMA user guide.
- Basic video display control from the Prisma remote of most video display brands and models, with setup done using the free ruwido infrared application.
- Updates will be made available using the ruwido infrared application to improve the remote functions, add features, and models.
- Backlighting allows for ease of use in low light.

PRISMA is configured to operate over 10 component categories with 21 layers controlling more than 54 models currently, with more models to be added by future update*:

AMP

- I15, I25, I35
- I22, I32, I21, I20, I30, A10, A20, A30.1

BD

- BD32, BD32 MK2

CD

- CD15, DD15, CD35, DD35
- D20, D30.2, CD21, CD31, CD22, CD32
- CDI10

DVD

- V10, V20, V25
- DVD26, DVD30
- DVDI10

MEDIA

- NP30, DAC30

OTHER

- Delay Box

PRE

- SC15, PRE35
- PRE30, PRE32, PRE60

TUNER

- T20
- T21, T22, T30
- T23

AV

- SPA25, SP25
- SP31.7, SPA20, SP31, SPA21, SP32, SPA22
- P30
- SP33, SPA23

TV

- Capable of controlling video displays from 1166 different brands representing approximately 160,000 models

* 928 and 200 series not yet available

