

C24

SYSTEM
REMOTE CONTROL

P R I M A R Y

USER GUIDE




CONTENTS

PROC MODE	4
BD MODE	5
MEDIA MODE	6
AMP MODE	7
CD MODE	8
PRE MODE	9


PROC MODE

For the SPA23 and SP33.




BD MODE

For the BD32.




MEDIA MODE

For the NP30 and DAC30.




AMP MODE

For the I22, I32, and older integrated Primare amplifiers.




CD MODE

For the CD22 and CD32.




PRE MODE

For the PRE32 and older Primare preamplifiers.



P R I M A R E

THE SOUND AND VISION OF SCANDINAVIA



PLEASE VISIT PRIMARE.NET FOR MORE
INFORMATION ABOUT OUR PRODUCTS

PRIMARE AB | LIMSTENSGATAN 7 | 21616 LIMHAMN | SWEDEN | PRIMARE.NET